


## **KEYED NOTES**

- 1. INSTALL NEW 1-1/2" DOMESTIC WATER SERVICE FROM THE STREET MIN 7FT DEEP, COORDINATE EXACT MATERIAL AND LOCATION WITH CIVIL, NEW WATER LINE SHALL ENTER THE BUILDING JUST ABOVE THE EXISTING WALL FOOTER. PROVIDE A LINK SEAL AROUND WALL PENETRATION.
- 2. INSTALL NEW 6" FIRE PROTECTION WATER SERVICE FROM THE STREET MIN 7FT DEEP. COORDINATE EXACT MATERIAL AND LOCATION WITH CIVIL. NEW WATER LINE SHALL ENTER THE BUILDING JUST ABOVE THE EXISTING WALL FOOTER.

PROVIDE A LINK SEAL AROUND WALL PENETRATION.

- 3. OFFSET AND ROUTE 6" FIRE PROTECTION LINE UP . LOCATE PIPING HIGH AND TIGHT TO THE CEILING AND THE BEAM OVER TO THE FIRE PUMP ROOM.
- 4. SEE FIRE PROTECTION SPECS FOR THE ROOM LAYOUT AND INSTALLATION. ALL WALL IN THIS ROOM HAVE A 1-HOUR
- 5. ROUTE 1-1/2" CW DOMESTIC LINE FROM THE WATER METER HIGH AND TIGHT AROUND THE PERIMETER OF THE ROOM TO THE BOOSTER PUMP AS SHOWN. 6. ROUTE DOMESTIC WATER LINES UP IN 2 HOUR CHASE TO SERVE THE REST OF THE BUILDING. SEAL PENETRATION AS
- REQ'D. SEE BASEMENT SHEET FOR CONTINUATION. 7. INSTALL 3/4" HW AND CW DOMESTIC WATER LINES DOWN TO LAUNDRY SINK EXPOSED. SUPPORT WITH UNI-STRUT
- AND CLAMPS AS REQ'D. 8. DO NOT INSTALL DOMESTIC WATER OF ANY KIND IN THIS ROOM.





PHASE 1 SUB-BASEMENT FLOOR PLAN -DOMESTIC PIPING

1/4" = 1'-0" 01