


- 3. COORDINATE LOCATIONS AND REQUIREMENTS WITH OTHER TRADES PRIOR TO FABRICATION OF MATERIALS. PLAN OFFSETS AS REQ'D TO AVOID CONFLICTS WITH DUCTWORK AND STRUCTURE.
- 4. COORDINATE EXACT KITCHEN EQUIPMENT ROUGH-IN TO ALL EQUIPMENT PRIOR TO INSTALLATION.
- PROVIDE BACKFLOW DEVICE AS REQ'D ON DISHWASHER, GARBAGE DISPOSAL, ICE MAKER, AND COFFEE MACHINE, ETC. IF NOT PROVIDED WITH EQUIPMENT, PROVIDE PER IPC AND AHJ.
 ALL PLUMBING ON THIS LEVEL TO BE ROLIGHED IN ONLY (BASE BID). FIXTURE LABELS SHOWN FOR ROLIGH-IN SIZING.
- 6. ALL PLUMBING ON THIS LEVEL TO BE ROUGHED-IN ONLY (BASE BID). FIXTURE LABELS SHOWN FOR ROUGH-IN SIZING ONLY. TRIM OUT TO BE IN THE FUTURE.
- 7. PROVIDE FIRE CAULKING AS REQ'D AROUND ALL PENETRATIONS IN AND OUT OF THE CHASE.



KEYED NOTES

- ALL WATER LINES ON THIS LEVEL TO BE SERVED FROM BELOW. SEAL ALL FLOOR PENETRATIONS WATER TIGHT AROUND INSULATION. SEE FIRST FLOOR DOMESTIC PLAN FOR CONTINUATION.
- 2 COORDINATE EXACT LOCATIONS OF FUTURE KITCHEN EQUIPMENT IN THIS ROOM PRIOR TO INSTALLATION OF ROUGH-IN PIPING.
- 3. PROVIDE AC BOXES IN THE WALL FOR APPROPRIATE KITCHEN EQUIPMENT. COORDINATE HEIGHT BELOW COUNTER TOP PRIOR TO INSTALLATION.
- INSTALL 2" CW LINE UP IN WALL FRAMING TO SERVE FIXTURES IN BOTH BATHROOMS, DISTRIBUTE ACCORDINGLY FROM THE 2" HEADER.
- 5. PROVIDE ACCESS DOOR AND SHUT OFF VALVE IN THE WALL FOR ACCESS TO THE SHOCK ARRESTER IN THE MEN'S BATHROOM. PROVIDE ACCESS DOOR ABOVE THE TILE, 5'-6" TO THE BOTTOM.
- 6. FIELD VERIFY THAT INSULATION IS INSTALLED IN ALL WALL CAVITIES THAT CONTAIN DOMESTIC WATER LINES IN THE EXTERIOR WALL. INSTALL INSULATED WATER PIPING ON THE WARM SIDE OF THE WALL IN ALL LOCATIONS. OFFSET INSULATION AS NEEDED.

PHASE 1 SECOND FLOOR PLAN -DOMESTIC PIPING

heet number

15 23

N PLAN NORTH

1/4" = 1'-0" 01