






GENERAL NOTES


- A. INSTALL ALL PLUMBING PIPING WITHIN FRAMED WALLS OR ABOVE CEILINGS TIGHT TO OR WITHIN STRUCTURE UNLESS NOTED OTHERWISE. COORDINATE LOCATIONS WITH OTHER TRADES PRIOR TO INSTALLATION. PLAN OFFSETS AS REQ'D TO AVOID CONFLICTS WITH DUCTWORK AND/ OR STRUCTURE.
- B. SLEEVE ALL WALL PENETRATIONS ALLOWING FOR FREE MOVEMENT DUE TO PIPE EXPANSION. SEAL PENETRATIONS THRU RATED CONSTRUCTION WITH A FIRE SAFE MATERIAL AND ALL OTHERS WITH AN ACOUSTIC CAULK.

KEY NOTES

1. INSTALL 6-IN COMMON WATER SERVICE AND FIRE SPRINKLER MAIN MIN 6-FT DEEP. INSTALL THRUST BLOCKING AT ALL WATER LINE CHANGES IN DIRECTION. COORDINATE FLANGE LOCATION WITH OTHER TRADES.
2. INSTALL NFPA COMPLIANT FIRE SPRINKLER RISER AND ACCESSORIES. CONNECT 2-IN WATER SERVICE TO THE FIRE RISER. SEE FP DRAWINGS FOR MORE INFORMATION.
3. INSTALL 2-IN WATER METER, REDUCED PRESSURE BACK-FLOW ASSEMBLY, AND OTHER DEVICES ON A FIELD FABRICATED 16-IN DEEP CHANNEL IRON FRAME SECURED TO THE FLOOR AND WALL.
4. INSTALL 1.5-IN IRRIGATION LINE DOWN INTO CRAWL SPACE AND EXTEND THRU FOUNDATION WALL AT A DEPTH OF 24-IN BFG. COORDINATE LOCATION WITH THE LANDSCAPER.
5. INSTALL 3-IN LOW PRESSURE GAS LINE HIGH-UP IN THE CRAWL SPACE. SLEEVE FOUNDATION AND EXTEND INTO MECH ROOM.
6. FIELD LOCATE DOMESTIC PIPING MAINS HIGH-UP ABOVE THE CORRIDORS AND / OR OFFICE AREAS AS SHOWN. CONFIRM CONDITIONS AND COORDINATE ROUTING WITH OTHER TRADES PRIOR TO ROUGH-IN.
7. SLEEVE FOUNDATION WALLS AND INSTALL DOMESTIC PIPING INTO AND ACROSS THE CRAWL SPACE HIGH-UP. OFFSET AND EXTEND PIPING UP WITHIN WALL FRAMING ABOVE.
8. OFFSET PIPING TO ACCOMMODATE NON-STANDARD BLDG ANGLES. OFFSET PIPING OVER OR UNDER STRUCTURE OR OTHER ELEMENTS AS NEEDED THRU-OUT THE BLDG.
9. INSTALL SHOCK ARRESTOR WITH ISOLATION VALVE IN RUN-OUT TO ALL FAST ACTING VALVES. LOCATE ABOVE THE TILE LINE PER ARCHITECT. PROVIDE STAINLESS STEEL ACCESS DOOR FOR INSTALLATION BY THE GC.
10. CONNECT DISHWASHER TO HOT WATER BRANCH AT ADJOINING SINK. PROVIDE TUBING AND SHUT-OFF.
11. EXTEND CW AND HW PIPING UP WITHIN CHASE OR WALL FRAMING TO SERVE FIXTURES ABOVE.
12. SEE LARGE SCALE PLUMBING ISOMETRICS FOR ADDITIONAL DOMESTIC PIPING INFORMATION IN THESE AREAS.
13. SEE LARGE SCALE PLAN FOR ADDITIONAL DOMESTIC PIPING SCOPE OF WORK IN THE ME ROOM.



TRONA VALLEY FEDERAL CREDIT UNION
1700 GATEWAY BLVD
ROCK SPRING, WY 82901



PROJECT
24112

DATE
09-27-2025

DRAWN BY
GMH

DISK ID.

SHEET
BASEMENT LEVEL
DOMESTIC PIPING

SHEET

15.30